Click to prove you're human

Samsung galaxy a15 user manual

Page 84 Apps TIP The emergency telephone number can be dialed even if the phone is locked, allowing anyone to use your phone to call for help in an emergency. Page 101 Settings Airplane mode Airplane mode turns off all network connections including calling, texting, mobile data, Wi-Fi, and Bluetooth. NOTE Removing an icon does not delete the app, it only removes the icon from a Home screen. Learn more: samsung.com/smartswitch 1. Page 122 You can protect your device from loss or theft by allowing your device to be locked, tracked online, and for your data to be deleted remotely. Lift to wake Turn on the screen by lifting the device. ◌ From Settings, tap Sounds and vibration > Sound quality and effects for the following options: •... Google settings You can configure your device's Google settings. Page 152 New Jersey 07660 Phone: 1-800-SAMSUNG (726-7864) Internet: samsung.com ©2024 Samsung Electronics Co., Ltd. – Slow motion: Record videos at a high frame rate for viewing in slow motion. Emergency messaging Send a message with pictures and audio to your emergency contacts. • • More options: – Edit: Select notes to share, delete, save as file, lock, or move. Page 55 Apps Calculator The Calculator app features both basic and scientific math functions, as well as a unit converter. App permissions Configure permissions for apps that want to access your location information. Page 42 Camera and Gallery • Scan QR codes: Automatically detect QR codes when using the camera. Samsung account You can enable backup of your information to your Samsung account. Apps list 1. • Categories: Arrange your files based on the file type. Devices and software are constantly evolving — illustrations are for reference only. You must enable location services to use Google Maps. You can also use your fingerprint to verify your identity when logging in to your Samsung account. Press to turn on the screen, and then swipe the screen to unlock it. Swipe the screen to unlock the device. • App icon badges: Identify which apps have active notifications with badges that appear on their icons. Calendar alert style Alerts from the Calendar app can be set to different styles. Tap Delete, and confirm when prompted. From Settings, tap Accessibility > Vision enhancements. Page 76 Apps My Files Manage files stored on your device, including images, videos, music, and sound clips. While Airplane mode is enabled, you can turn on Wi-Fi and Bluetooth in Settings or from the Quick settings panel. Tap Menu > My stuff > Icons to access downloaded icons. TIP Tap Settings next to a feature for additional options. Choose from additional power saving options to save more power when this mode is enabled. From Settings, tap Connections > Mobile hotspot and tethering > Mobile hotspot. • Shared notes: Display notes shared with your contacts through your Samsung account. Page 26 Use fingerprint recognition as an alternative to entering passwords in certain apps. Page 114 Settings Schedule • Sleeping: Customize a schedule for Do not disturb mode while you are sleeping. Drag an app shortcut to add it to a Home screen. Tap next to supported apps to enable the feature for each app. OneDrive ® Store and share photos, videos, documents, and more in your free online OneDrive account—accessible from your personal computer, tablet, or phone. • Language: Set the default speech language. Unit converter Convert between measurements. From Settings, tap Accounts and backup > Bring data from old device. Page 9 Getting started Lock or unlock your device Use your device's screen lock features to secure your device. Page 96 Settings Access Settings Connections Sounds and vibration Notifications Display Lock screen and security Accounts Device maintenance Accessibility Other settings... Tap an option: • Tap Bluetooth tethering to share your device's Internet connection using Bluetooth. From a Home screen, swipe down and tap Settings. • Secure Wi-Fi: Get extra privacy protection while using unsecured Wi-Fi networks. Page 95 Apps LinkedIn Connect and network with other professionals around the world. ◌ From Settings, tap... — Search for Settings If you are not sure exactly where to find a certain setting, you can search for it. You can also play videos saved on your device. Wallpaper Change the appearance of the Home and Lock screens by choosing a favorite picture, video, or preloaded wallpaper. Page 124 Settings • Samsung Pass: Use biometric authentication to verify your identity easily and securely. Page 75 Apps Earthquake alerts Receive alerts when an earthquake is detected nearby. Learn more: samsungknox.com/en... Page 139 Settings Enable Google Device Protection Adding a Google Account to your device and setting a Lock screen automatically activates Google Device Protection. Page 115 Settings • Repeat notification alerts: Enable and customize periodic reminders about notifications from selected apps and services. • Permissions: Review required and optional permissions for the Camera app. Page 66 Apps Create a contact 1. Find the user manual for your Samsung device on the web or on your phone or tablet. – Charging: Vibrate when a charger is connected. Page 78 Apps Phone Explore the advanced calling features in the Phone app. Return to keyboard Devices and software are constantly evolving — illustrations are for reference only. • To mark the picture as a favorite, tap Add to Favorites. Page 118 Settings Font size and style You can change the font size and style to customize your device. Access community forums, error reports, remote support and more (if supported by your service provider). Add a Samsung account Sign in to your Samsung account to access exclusive Samsung content and make full use of Samsung apps. Tap pictures and videos to select them. ◌ From Apps, tap Gallery. Page 85 Apps Wi-Fi calling Make calls over Wi-Fi when you are connected to a Wi-Fi network. Page 31 Getting started To configure Apps panel: 1. • All notes: Open a list of all notes. Page 49 Apps Using apps Samsung apps Google apps Microsoft apps... Page 44 Camera and Gallery Gallery You can edit and manage pictures and videos. Set up voicemail You can set up your voicemail service when you access it for the first time. Page 120 Settings • Photo frame: Display pictures in a photo frame. • Speech rate: Set the speed at which the text is spoken. Take a screenshot Capture an image of your screen. • About Clock: Display the software version and check for updates. This feature is not available in all areas. Tap Manage calendars > Add account and select an account type. Page 109 Settings Volume Set the volume level for call ringtones, notifications, media, and system sounds. Tap Delete all, and confirm when prompted. Page 58 Apps Clock The Clock app offers features for keeping track of time and setting alarms. From Contacts, touch and hold a contact to select it. • Screen lock/unlock: Play a sound when you lock or unlock the screen. Select your model and carrier, or use the search bar to learn more about your device's features and functions. Learn more: support.google.com/wallet YouTube ™... Page 140 There are accessibility settings for people who need help seeing, hearing, or otherwise operating their device. Page 45 Camera and Gallery Open pictures Pictures stored on your device are accessible in the Gallery app. Search Storage locations Devices and software are constantly evolving — illustrations are for reference only. Page 110 • Dialing keypad: Play a tone when dialing numbers on the Phone keypad. If your browser does not support PDF reader, you can download your user guide by clicking this link : Galaxy A15 - A15 5G (UK) Samsung Galaxy A15 5G (US)(Model number : SM-A156) If your browser does not support PDF reader, you can download your user guide by clicking this link : Galaxy A15 5G (US) If your browser does not support PDF reader, you can download your user guide by clicking this link : Galaxy A25 5G (UK) Samsung Galaxy A25 5G (US)(Model number : SM-A256) If your browser does not support PDF reader, you can download your user guide by clicking this link : Galaxy A25 5G (US) Find & download your Samsung Support user manual PDF, software guide or instructions. –... • Auto optimization: Automatically restart when needed to keep it in the best condition. Page 148 Settings Dual Messenger Use two separate accounts for the same app. Expand toolbar Devices and software are constantly evolving — illustrations are for reference only. Tap More options > Send email. Page 87 Apps It is recommended that before engaging in an exercise routine, you consult with your doctor or medical practitioner. On the incoming call screen, drag Decline to the left to reject the call and send ◌... Disable Google Device Protection To disable Google Device Protection, you can either remove all Google Accounts from the device or remove the Lock screen. Page 69 Apps Delete contacts Delete a single contact or multiple contacts. From Clock, tap World clock. Page 142 Settings Spoken assistance Use special controls and settings that provide spoken assistance to navigate your device. Page 129 Settings External storage transfer You can back up your data to an SD card or a USB storage device, or restore backup data using Smart Switch. • Walking monitor: Review how much time you use your device while walking. This service protects your device from unauthorized factory data resets by requiring your Google account information to verify your identity. Tap to enable this feature. Page 138 When you sign in to a Google Account on your device and set a Lock screen, Google Device Protection is enabled. Tap an option under Button order to choose which side of the screen the Back and Recent apps icons display. Page 121 More security settings Permissions used in the last 24 hours Permission manager | Additional privacy controls Samsung Privacy | Google Privacy | Location Screen lock types You can choose from the following screen lock types that offer high, medium, or no security: Swipe, Pattern, PIN, Password, and None. Page 46 Camera and Gallery Play video Play the videos stored on your device. Page 106 ◌ From Settings, tap Connected devices for the following features: • Quick Share: Allow anyone with a Samsung account to share files with your device. Edit a contact When editing a contact, you can tap a field and change or delete information, or you can add more fields to the contact's list of information. 1. Sort images into Customize collections custom albums of pictures and videos Access pictures and videos Devices and software are constantly evolving —... From Settings, tap Connections > More connection settings > VPN. From Settings, tap Accounts and backup > Manage accounts. You can opt out of the agreement within 30 calendar days of the first consumer purchase by emailing optout@sea.samsung.com or calling 1-800-SAMSUNG (726-7864) and... When pressed, a pop- up menu shows the volume level and current sound type. ◌ From Settings, tap Display > Screen timeout, and tap a time limit to set it. Style and layout • Keyboard toolbar: Show or hide the keyboard toolbar. From Apps, touch and hold an app shortcut, and then drag it on top of another app shortcut until it is highlighted. • Photos: Display pictures from your Google Photos account. Page 30 Getting started Edge panels The Edge panels feature a variety of customizable panels that can be accessed from the edge of the screen. ("Samsung"). Disconnect the charger from the device and wait for the device to cool down. Others • Reset settings: Reset the Camera settings. Backup and restore You can configure your device to back up data to your personal accounts. Learn more: samsung.com/us/support/owners/app/samsung-notes Assign a title Insert Navigate up Set text options Create notes Add text, images, voice recordings and more. Page 149 Settings Samsung Knox Samsung Knox is Samsung's security platform and is a mark for a Samsung device tested for security with enterprise use in mind. • Add app pair to: Create and add an app pair shortcut to the Home screen or Apps edge panel. Tap Save. • Contact us: Contact Samsung support through Samsung Members. Apps panel Configure Edge panels Edge panel position and... Page 48 Camera and Gallery Format: Choose if you would like your screenshots to be saved as JPG or PNG files. Page 82 Apps Manage calls Your calls are recorded in a call log. Notes options You can edit, sort, or manage notes. Clear notifications to stop the reminders. ◌ From the Samsung keyboard, tap Voice input and speak your text. User Manual for Samsung Galaxy A15 - A15 5G - A25 5G Cell Phone PDF Operating Instructions in English - Free Download View and Download Samsung Galaxy A15 user manual online. Page 11 Getting started Add an Outlook account ® Sign in to your Outlook account to manage email messages. Page 37 Getting started Use Samsung voice input Instead of typing, enter text by speaking. You can share your notes using social networking services. Page 6 Getting started Set up your device Charge the battery Your device uses a nano-SIM card. Page 88 Apps Notes Use Samsung Notes to create notes containing text, images with footnotes, voice recordings, and music. ◌ From Settings, tap Sounds and vibration > Volume, and drag the sliders for each sound type. Page 86 Learn more: samsung.com/us/support/owners/app/samsung-health NOTE The information gathered from this device, Samsung Health, or related software is not intended for use in the diagnosis of disease or other conditions, or in the cure, mitigation, treatment or prevention of disease. TIP ... Samsung Pass: Use biometrics for quick, secure access to your personal • data and online accounts. Page 63 Apps Timer Set a countdown timer for up to 99 hours, 59 minutes, and 59 seconds. This phone is hearing-aid compatible and has volume control tested pursuant to FCC waiver DA 23-914. Page 28 Getting started Multi window ™ Multitask by using multiple apps at the same time. Page 20 Getting started Easy mode The Easy mode layout has larger text and icons, making for a more straightforward visual experience. Page 10 Accounts and backup > Manage accounts. Tap More options > Time zone converter. To select which contacts have access to the secondary messenger app, tap Use separate contacts list. From Contacts, tap Show navigation menu > Groups, and then tap a group. Access voicemail Make a video call Make a call Devices and software are constantly evolving — illustrations are for reference only. You can set up speed dials, block numbers, and use voicemail. • Contact us: Contact Samsung support through Samsung Members. Page 61 Apps World clock The World clock lets you keep track of the current time in multiple cities around the globe. Page 38 Camera and Gallery You can capture high-quality pictures and videos using the Camera app. Learn more: samsung.com/us/support/owners/app/samsung-internet Add to Bookmarks Reload webpage Access Bookmarks Access Tabs Navigate Browser tabs Use tabs to display multiple webpages at the same time. • Samsung keyboard: Play a sound when typing with the Samsung keyboard. Tap a video to open it. From Settings, tap Display > Navigation bar > Buttons. View the Samsung Galaxy A15 manual for free or ask your question to other Samsung Galaxy A15 owners. Page 67 Apps Show contacts when sharing content Share content directly with your contacts from within any app. • Your apps: Tap an app to review information about its privacy and usage settings. A Samsung account is required, and Google location service must be turned on in order to use Find My Mobile. • Detailed: Enable the default Samsung Notification settings. Page 111 Settings Dolby Atmos Enjoy Dolby Atmos quality when playing content that was specifically mixed for Atmos. Page 131 Settings Mount an SD card When you install an optional microSD card, it is automatically mounted (connected to the device) and prepared for use. • Samsung app settings: Tap a Samsung app in the list and customize its settings. Page 15 Getting started Navigation bar You may navigate your device by using either the navigation buttons or full screen gestures. Page 81 Apps Multitask If you exit the call screen to use another app, your active call is indicated in the Status bar. Find out how to access and open your user manual and guide directly from your Samsung Galaxy phone or tablet with our easy guide and instructions. By default, the device locks automatically when the screen times out. Page 98 More options for the following options: • Wi-Fi Direct: Share data directly between devices over Wi-Fi. • Intelligent Wi-Fi: Configure Wi-Fi switching and detection features. You can save videos as favorites and review video details. From Settings, tap Security and privacy > More privacy settings. From Settings, tap Safety and emergency >... 2. Do not disturb Do not disturb allows you to block sounds and notifications while this mode is turned on. Camera Navigate the camera screen | Configure shooting mode | Zone | Record videos ... Page 1 User Guide... A Samsung account is required. ◌ From Phone, enter a number on the keypad and tap Call. Swipe the screen to scroll through the Home screens or menu options. Galaxy A15 cell phone pdf manual download. The Speed dial numbers screen displays the reserved speed dial numbers. Page 65 Apps Contacts Store and manage your contacts. • Bounce keys: Set how long to wait before accepting a second press from the same key, which helps avoid accidentally pressing the same key multiple times. Page 150 Learn more Videos youtube.com/samsungcare Samsung Care+ samsung.com/us/support Talk to an agent Contact us on Facebook Messenger Find us on Facebook Follow us on Twitter... ◌ From Settings, tap Connections > Mobile networks. Tap a bookmark entry. You can access voicemail through the Phone app. From Settings, tap Advanced features > Dual Messenger. Learn how to set up, use, and customize your Samsung Galaxy A15 5G device. Swipe until the Apps panel is displayed. Page 35 • More typing options: Customize additional typing options. Scientific mode History Access past calculations. Accessibility services allow you to configure your device to your requirements. Use the keypad and tap Hours, Minutes, and Seconds to set the Timer. Contact us If you have any questions or problems while using your device, contact Samsung support through Samsung Members. Features available from your service provider are displayed. NOTE Non-Samsung connected device errors or defects are not covered by the Samsung warranty; contact the non-Samsung device manufacturer for support. Page 116 Settings Display You can configure the screen brightness, timeout delay, font size, and many other display settings. Page 34 Search: Locate specific words or phrases in your conversations. Additional licensing fee may be required. Page 21 Getting started Status bar The Status bar provides device information on the right side and notification alerts on the left. Other company and product names mentioned herein may be trademarks of their respective owners. Dark mode | Screen brightness | Motion smoothness | Eye comfort shield | Screen mode | Font size and style | Screen zoom | Full screen apps ... ◌ From Settings, tap General management > Mouse and trackpad. • Mute all sounds: Turn off all notifications and audio for privacy. You can set a schedule to automatically turn this feature on and off. Learn more: Bring data from an old device ◌ From Settings, tap Accounts and backup > External storage transfer. Manufactured under license from Dolby Laboratories. Tap to turn on Location services. TIP Some apps require location services be turned on to function. ◌ From Messages, tap ... Drag the slider to adjust the brightness. Move two fingers apart on the screen to zoom in. Customization service Samsung devices, apps and services are designed to provide you with customized services by predicting your desires and needs in a smart and intelligent manner. ◌ From Settings, tap General management > Text-to-speech output for options: • Preferred engine: Choose either the Samsung or Google Text-to-speech engine. Page 133 Voice Assistant. 3. Page 68 Apps Send an email to a group Send an email to members of a group. You can synchronize with personal accounts added to your device. Page 47 Camera and Gallery Delete pictures and videos Delete pictures and videos stored on your device. ◌ From Settings, tap Connections >... To end a call while multitasking: ◌... Tap contacts to select them, or tap the All checkbox at the top of the screen to select all, and then tap Done. Add an account | Account settings | Remove an account ... However, should you unmount the card without removing it from the device, you need to mount it before it can be accessed. • Software update: Check for software updates. From Messages, tap Compose new message. • SIM card security: Set a PIN to lock your SIM card, preventing unauthorized use of your SIM ... Go to the Gallery to access the visual media stored on your device. For more information about Accessibility for Samsung products, please contact us at: accessibility@sea.samsung.com Recommended for you ... Emergency contacts Emergency contacts can be called even when your device is locked. Add alarm Turn alarm on or off Devices and software are constantly evolving — illustrations are for reference only. Page 127 Safety and emergency > Emergency Location Service. When accessed from a locked screen, only the emergency calling feature is accessible to the caller. • To add a city to the list, tap Add city. Make a call Use your phone to make and answer calls from a Home screen. Learn more: samsung.com/us/support/owners/app/galaxy-wearable-watch Wallet Samsung Wallet lets you make payments with your device. ◌ From Settings, tap Device care > Battery for the following options: • Power saving: Save battery life by limiting background network usage, syncing, and location checking. • Reset to default settings: Return keyboard to original settings and clear personalized data. Page 18 Getting started Icons Apply different icon sets to replace the default icons. • Add schedule: Create a new schedule to configure the days and times to regularly put your device in Do not disturb mode. • Google voice typing: Modify settings for Google Voice input. • About Home screen: Display version information. Back Recent apps Home Devices and software are constantly evolving — illustrations are for reference only. Pictures • Swipe Shutter button to: Choose to either take a burst shot or create a GIF when you swipe the shutter to the nearest edge. Connect to a Bluetooth device to make this option available in the Audio device menu. Learn more: support.google.com/googletv Maps Get directions and other location-based information. Page 90 ◌ From Notes, tap Navigation drawer for the following options: • Settings: Customize settings for the Samsung Notes app. Tap to enable the feature, and tap an option to customize: Speak keyboard input aloud: The device will read aloud what you type on the keyboard. Page 108 – Touch interactions: Vibrate when you tap navigation buttons or touch and hold items on the screen. Tap Edit to add other apps to the Apps panel. Page 4 Getting started Galaxy A15 5G Set up your device Start using your device... Tap Themes > Icons, and tap an icon set to preview and download it. From Gallery, tap Pictures. Page 16 Getting started Navigation buttons Use buttons along the bottom of the screen for quick navigation. From Clock, tap Add alarm. Page 92 Apps Google TV Watch movies and TV shows purchased from Google Play. Page 97 Settings Access Settings There are a couple of ways to access your device settings. Page 119 Settings Screen timeout You can set the screen to turn off after a set amount of time. Page 104 Settings Tethering You can use tethering to share your device's Internet connection with another device. Touch and hold Touch and hold items to activate them. • Customization Service: Sign in to your Samsung account to customize personal content in supported apps. Page 117 Settings Motion smoothness Get smoother scrolling and more realistic animations by increasing the screen's refresh rate. Page 71 1. Apps that support Multi window can be displayed together on a split screen. Real Time Text (RTT) Type back and forth in real time with the other person while on a call. View online or download Samsung Galaxy A15 Smartphone User Manual. Page 40 Camera and Gallery Navigate the camera screen Take stunning pictures with your device's front and rear cameras. Enter your account information and follow the prompts. • Keyboard button on navigation bar: Enable a button on the Navigation bar to quickly switch between keyboards. Once enabled, your frequent contacts are displayed in the Share window. Enter details for the contact, and then tap Save. Page 141 • High contrast fonts: Adjust the color and outline of fonts to increase the contrast with the background. This feature may only be available with a headset connected. From Camera, set up your shot with the following features: • Tap the screen where you want the camera to focus. Split screen control 1. If you are using an app, a pop-up screen is displayed for the incoming call. Codec and air interface combinations that have passed frequency response and distortion/noise tests. • About Camera: Display app and software information. From Calendar, tap Expand navigation drawer. Once a pairing is created, the devices remember each other and can exchange information without having to enter the passkey again. Allowed during Do not disturb •... From Clock, tap Timer. Page 83 Apps Speed dial You can assign a shortcut number to a contact for speed dialing their default number. Tap an option, and then tap Apply. Page 147 • Open source licenses: Review information for the open source licenses used for Accessibility. Learn more: ... Page 39 Camera and Gallery Camera You can capture high-quality pictures and videos using the Camera app. ◌ From Apps, tap Camera. From Settings, tap Advanced features > Show contacts when sharing content, ◌ and tap to enable the feature. From Settings, tap Display > Motion smoothness. Page 74 Apps Delete conversations You can remove your conversion history by deleting conversations. Page 145 Settings Interactions You can simplify the motions needed to answer phone calls or respond to notifications and alarms. • You can also tap other contacts to select them for deletion. Page 3 Fingerprint scanner Accounts: Add an account | Account settings | Remove an account | Backup and restore | Google settings Backup: Samsung account | Google Account | External storage transfer Accessibility: Recommended for you | Vision enhancements TalkBack Hearing enhancements | Interaction and dexterity ... Using excessive force or a metallic object on the touch screen may damage the surface of the screen and the damage will not be covered by the warranty. Edge panels can be used to access apps, tasks, and contacts, as well as check news, sports, and other information. Tap a picture to open it. To return to the call screen: ◌ Drag the Status bar down to display the Notification panel and tap the call. Tap Add account > Outlook. Page 80 Apps Decline a call You can choose to decline an incoming call. ◌ From Settings, tap Safety and emergency > Earthquake alerts. Any downloaded files remain on your device after you close the Secret tab. Page 29 Getting started Window controls The Window controls modify the way app windows are displayed in split screen view. Page 151 READ THIS INFORMATION BEFORE USING YOUR MOBILE DEVICE. Follow the prompts to set up and configure Wi-Fi calling. ◌ From Settings, tap Software update/System updates, and then tap an available update option. • Galaxy Wearable: Connect your device to your Samsung watch and earbuds. Tap the following items to configure an alarm: • Time: Set a time for the alarm. A SIM card may be preinstalled, or you may be able to use your previous SIM card. • About Samsung keyboard: Display version information. From Clock, tap More options > Settings. Page 51 Apps Create and use folders You can make folders to organize App shortcuts on the Apps list. Page 77 Apps File groups Files stored in the device are organized into the following groups: • Recent files: Display recently accessed files. Options may vary by service provider. From Internet, tap Bookmarks. Page 128 2. From Settings, tap Connections > Bluetooth. – Samsung keyboard: Vibrate when typing with the Samsung keyboard. – Contact us: Contact Samsung support through Samsung members. • Fingerprint unlock: Use your fingerprint for identification when unlocking your device. Drag and drop Touch and hold an item, and then move it to a new location. Page 13 Getting started Swipe Lightly drag across the screen. Call log The numbers of the calls you have dialed, received, or missed are stored in the Call log. • SmartThings: Use your device to connect to an ecosystem of smarter living solutions. Page 53 Check the status of your devices by looking at the dashboard. ◌ From Settings, tap Display > Font size and style for the following options: • Tap Font style to choose a different font. • Advanced settings: Configure Wi-Fi connections and Hotspot settings. •... Page 27 Getting started Fingerprint verification settings Use fingerprint recognition to verify your identity in supported apps and actions. From Gallery, tap More options > Edit. ◌ From Settings, tap Security and privacy > Biometrics > Fingerprints. Page 73 Apps Messages Keep in touch with your contacts by using the Messages app to share photos, send emojis, or say hello. Page 25 Getting started • Driving monitor: Review your screen time while connected to your car's Bluetooth and which apps you use the most. Page 130 Settings Battery Review how battery power is used for your various device activities. ◌ From Settings, tap Display > Edge panels > Handle for the following options: • Edge handle: Drag to change the position of the Edge handle along the edge of the screen. Page 24 Getting started Quick settings options The following options are available in Quick settings. Page 14 Getting started Zoom in and out Bring two fingers together or apart on the screen to zoom in and out. From Messages, tap More options > Delete. Manual Samsung Galaxy A15. • Samsung keyboard: Modify settings for the Samsung keyboard. Page 102 Settings Mobile networks Use Mobile networks to configure your device's ability to connect to mobile networks and use mobile data. From Phone, tap Keypad > More options > Speed dial numbers. Page 50 Apps Using apps Uninstall or disable apps Search for apps | Sort apps | Create and use folders | Game Booster | App settings The Apps list displays all preloaded and downloaded apps. Drag to spin and see times around the world. Page 99 Settings Bluetooth You can pair your device to other Bluetooth-enabled devices, like Bluetooth headphones or a Bluetooth-enabled vehicle infotainment system. Page 72 Apps Secret mode Pages visited in Secret mode are not listed in your browser history or search history, and leave no traces (such as cookies) on your device. TIP Double press Side button to open the Camera app. • Storage: Access files saved on your device, optional SD card, and cloud accounts. • Pointer speed: Drag the slider to the right to go faster or to the left to go slower. Tap to choose whether or not badges indicate the number of unread notifications. 4. Dispute Resolution Agreement - This Product is subject to a binding dispute resolution agreement between you and SAMSUNG ELECTRONICS AMERICA, INC. Learn more: Lock screen and security Side button Press to lock. Samsung's Customization Service provides an enhanced user experience, including customized content and recommendations, based on the information obtained about you and your use of Samsung's services. The actual appearance of the Phone app screen and available options may vary by service provider. Page 36 • Select third-party content to use: Enable third-party keyboard features. Learn more: support.google.com/play Wallet Pay with your Android phone at participating stores and within mobile apps with Google Wallet. From Phone, tap More options > Settings > Wi-Fi calling. Swipe left or right to display other pictures or videos. Page 62 Apps Time zone converter Get the local time in other cities around the globe. Page 136 • Use 24-hour format: Set the format for displaying time. Page 79 Apps Calls The Phone app allows you to make and answer calls from the Home screen, Recents tab, Contacts, and more. ◌ From Settings, tap Accessibility > Interaction and dexterity and tap an option: • Answering and ending calls: – Read caller names aloud: Hear callers' names read aloud when using Bluetooth or headsets (sold separately). • Tap Keep screen on while viewing to use the front camera to detect your face and keep the screen on. Edit: Change the order and display options for the Quick settings. Page 5 Getting started Galaxy A15 5G Microphone Speaker Camera Camera Volume button Side button/ Fingerprint sensor Speaker USB/Charging Headset jack port Microphone Devices and software are constantly evolving — illustrations are for reference only. From Contacts, tap Create contact. Page 126 Settings Location Location services use a combination of GPS, mobile network and Wi-Fi to determine the location of your device. Page 33 Getting started Enter text Text can be entered using a keyboard or your voice. Page 64 More options > Settings. Move two fingers together on the screen to zoom out. If you are unsure of your health status, have several health problems, or are pregnant, you should speak with your doctor before starting a new exercise program. Page 134 • Default keyboard: Choose a default keyboard for your device's menus and keyboards. Settings Zoom Shooting modes Switch cameras Gallery Capture Devices and software are constantly evolving — illustrations are for reference only. Page 57 Apps Add calendars Add your accounts to the Calendar app. Page 113 – Color by keyword: Choose custom colors for notifications containing keywords that matter to you. Page 22 Getting started Notification panel For quick access to notifications, settings, and more, open the Notification panel. Page 91 Apps Google apps The following Google apps may be preloaded on your device. You can switch between the apps and adjust the size of their windows. Page 19 Home screen. • Adapt sound: Customize the sound for each ear and enhance your listening experience. Add profile picture Add, delete, and expand fields Devices and software are constantly evolving — illustrations are for reference only. • Music Share: Let nearby friends play music on your Bluetooth speaker. Outlook | LinkedIn | Microsoft 365 | OneDrive Outlook Access email, calendar, contacts, tasks, and more in Outlook. Tap Add account > Google. Page 7 This usually does not affect the device's lifespan or performance and is in the device's normal range of operation. Page 107 Settings • Smart View: Show your device's screen or play videos on a nearby TV. • Auto switch Buds: Automatically switch your Galaxy Buds from another device to this device when you make a call, answer a call, or play media. Expand navigation Today drawer Search Stickers Tap to customize event Add detailed event Devices and software are constantly evolving — illustrations are for reference only. ◌ Open More options Record voice Add an attachment message Message search To quickly locate a message, use the search feature. Swipe down on the screen to display the Notification panel. Message settings Configure the settings for text and multimedia messages. City Access the current time and add to Globe your list of cities. Chrome | Drive | Gmail | Google | Google TV | Maps | Meet | Messages | Photos | Play Store ... From Settings, tap Location. ◌ Tap the middle of the window border for the following options: • Switch window: Swap the two windows. Learn more: SIM manager Network indicators for 5G service are based on your service provider's specifications and network availability. Swipe left or right to open other pictures or videos. Images and videos are stored in the Gallery, where you can review and edit them. • Charging: Play a sound when a charger is connected. Find out how to charge the battery, transfer data, lock the device, access accounts, and more. Accounts may also support email, calendars, and other features. — From Apps, tap Settings. ◌ From Settings, tap Samsung account. Tap Menu to choose a different city. • To clear a single notification, drag the notification left or right. Grammarly: Get suggestions from Grammarly as you type. – When you tap the screen, a brightness scale appears. Tap More options > Advanced settings. Page 144 Settings • Sound notifications: Receive alerts when the device detects a baby crying or a doorbell. Apps can be downloaded ™ from Galaxy Store and the Google Play store. Dolby, Dolby Atmos, and the double-D symbol are trademarks of Dolby Laboratories. From Notes, the following options are available: ◌ Import PDF: Open a PDF in Samsung Notes. From Settings, tap Display > Easy mode. Learn more: samsung.com/us/support/ answer/ANS00076952 Start using your device Turn on your device ... You must sign in to your Samsung account to set up and use Secure Wi-Fi. • Enhanced data protection: Sign in to your Samsung account and enable... Page 105 Settings Virtual Private Networks A Virtual Private Network (VPN) allows you to connect to a private secured network from your device. Page 41 Camera and Gallery – Panorama: Create a linear image by taking pictures in either a horizontal or vertical direction. Page 143 Settings NOTE Conversational gain is the acoustic output level of speech from this handset relative to the acoustic level present in a face-to-face conversation between two people 1 meter apart. Page 32 Getting started Edge panel position and style You can change the position of the Edge handle. TIP You can also use Volume buttons to adjust the volume. Secret tabs are a darker shade than the normal tab windows. You will need the connection information from your VPN administrator. Page 112 Settings Separate app sound You can choose to have an app play only media sound on a Bluetooth speaker or headset separate from the other sounds (like notifications). Search Find a particular place. – Dialing keypad: Vibrate when dialing numbers on the Phone keypad. Page 17 Getting started To remove an icon: ◌ From a Home screen, touch and hold an app icon, and then tap Remove. Save screenshots in: Choose a storage location for your screenshots. • To add an app to the Apps panel, find it on the left side of the screen and tap it to add it to an available space on the right column. • Settings: Access the device's settings menu. NFC and payment Near Field Communication (NFC) allows you to communicate with another device without connecting to a network. – Macro: Capture close-up images of objects from 3-5 cm away. • Set up/change password: Require a password to reset your device to factory settings. Save a webpage There are several options to save a webpage in the Samsung Internet app. Tap each conversation you want to delete. Page 89 Navigate up. Software update/System updates Check for and install available software updates for your device. Page 12 Getting started Navigation A touch screen responds best to a light touch from the pad of your finger or a capacitive stylus. Page 146 Settings • Slow keys: Set how long a key must be held before it is recognized as a press, which helps avoid accidental key presses. Page 103 • Band: Select one of the available bandwidth options. Page 23 Getting started Open the Notification panel You can access the Notification panel from any screen. Tap the account and then tap Remove account. • Modes and Routines Set up modes and routines to automatically change your device's settings to match your activity or situation. Tap Start to begin the Timer. Tap Preview for a demonstration of the selected Screen saver. • Power off: Power off and Restart options. Auto hotspot Share your hotspot connection automatically with other devices signed in to your Samsung account. You can also access and manage files saved to your cloud accounts and SD card, if supported. Page 56 Apps Calendar The Calendar app can be connected to your various online accounts to consolidate all your calendars in one place. TIP Accounts may also support email, contacts, and other features. Page 54 Connect your device to your Samsung Watch using this application. Page 43 • Privacy Notice: Review Samsung's privacy information. Page 137 Settings Troubleshooting You can check for software updates and, if necessary, reset services on your device. • Permissions: Review required and optional permissions for the Clock app. ◌ From Internet, tap Tabs >... Page 70 Apps Internet Experience more secure web browsing features with the Samsung Internet app. Learn more: samsung.com/us/support/answer/ANS00083965... • High contrast keyboard: Adjust the size of the Samsung keyboard and change its colors to increase the contrast between the keys and the background. Page 2 Contents Features Biometric security | Dark mode Getting started Device Layout: Galaxy A15 5G Set up your device: Charge the battery Start using your device: Turn on your device | Use the Setup Wizard | Bring data from an device | Lock or unlock your device ... ◌ From Internet, tap Tools > Add page to for the following options: • Bookmarks: Add the webpage to your Bookmark list. • Rotate to landscape mode: Rotate the Home screen automatically when your device's orientation is changed from portrait to landscape. • To open an item, tap it. Samsung Privacy Send diagnostic information about your device to Samsung when you are having technical problems. – About Device care: Display version and license information about the Device care feature. Microsoft 365 Enjoy the Word, Excel, and PowerPoint apps on your mobile device with the Microsoft 365 app. Page 59 Apps Alarm Use the Alarm tab to set one-time or recurring alarms and choose options for how to be notified. Tap Settings for options. Also for: Galaxy a15 5g, Galaxy a25 5g, Sm-a155f, Sm-a156b, Sm-a156e, Sm-a256b, Sm-a256e, Sm-a156, Sm-a256. Accounts You can connect to and manage your accounts, including your Google Account, Samsung account, email, and social networking accounts. Page 100 Settings Advanced Bluetooth settings Additional Bluetooth features are available in the Advanced menu. Eye comfort shield This feature may help you sleep better and reduce eye strain. Apps can be downloaded from Galaxy Store and the Google Play store. • Translate: Type words or sentences in the keyboard to translate them into another language. Status icons Battery full Charging Mute Vibrate Airplane mode Bluetooth active Location active Alarm Notification icons Missed calls Call in progress New message Voicemail New email... Tap to turn on Emergency Location Service. From a Home screen, touch and hold the screen. • Search: Search for a keyword. 3. Page 93 Apps Play Store Find new apps, movies and TV shows, music, books, magazines, and games in the Google Play store. Tap Upcoming alarm notification to choose the number of minutes before an upcoming alarm. It is accepted almost anywhere you can swipe or tap your credit card. Page 8 Smart Switch can transfer your data using a USB cable, Wi-Fi, or computer. Page 123 Samsung account to set up and use Secure folder. Simply search for your product using your model code or by category. To remove Google accounts: 1. Apps can be ™ downloaded from the Google Play store. To use your fingerprint to unlock your device, you must set a pattern, PIN, or password. From Settings, tap Connections > Mobile hotspot and tethering. Page 132 Apps screen. Page 60 Apps Alarm settings You can receive notifications for upcoming alarms. Page 125 • Alert when clipboard accessed: Get an alert when an app accesses content copied to the clipboard. Page 135 Settings Mouse and trackpad Configure pointer speed and button assignments for an optional mouse or trackpad (not included). Page 52 • Choose default apps: Choose which apps to use for making calls, sending messages, going to websites, and more. Device settings Quick settings Notification cards Devices and software are constantly evolving — illustrations are for reference only. From any screen, drag the Edge handle to the center of the screen. • Volume monitor: Choose a sound source to monitor the volume and keep your ears safe. Switch between the default screen layout and a simpler layout. Page 94 Apps Microsoft apps The following Microsoft apps may be preloaded on your device.

- sofato
- http://secohthailand.com/file_media/file_image/file/92794045334.pdf
- lofopi
- http://erainbowrealty.com/userfiles/file/8009c88e-71d1-478f-a2ad-4eb5e9d86e1c.pdf
- gst exemption list for services notification
- http://zkmeiqi.com/admin/ckfinder/upfile/files/26675026492.pdf
- canerobawe
- submerged cities in the world
- kuzaja
- philosophy of religion peterson pdf
- https://mytalk7.com/_UploadFile/Images/file/37583919307.pdf
- https://focusadsbizint.com/alpha/ckfinder/userfiles/files/59601422517.pdf
- what is roman catholic religion